

Reset Scale 1 TCIS-2 to Factory Default Settings with Static IP

To reset:

1. While **pressing any button**, power up the station by connecting to a PoE switch.
2. Hold the button until the station audio starts counting, and release the button on **count 1**.
3. Press and hold the button on **count 3** and release on **count 0**.
- if there is no 0 count, the procedure has failed and you have to start again
4. Press the **call button**, and the station will speak its IP address.



Factory Default with Static IP Address

Factory default values

- Station IP address: **169.254.1.100**
- Username: **admin**
- Password: **alphaadmin**
- Mode of operation: **Edge**

Upload Config File to the TCIS-2 Scale 1 Intercom

1. Enter the IP address of the Scale 1 Turbine TCIS-2 into your web browser and log in.
2. Under **Main > Recovery** click on Advanced configuration mode and type in the password 1851
3. Put a checkmark in the box and click **Save**.
4. Click **Reload**.

Now to upload the configuration file.

1. Click the **Station Administration > Recovery**
2. Click the **Browse** button and find the ipst_config.tar you downloaded from our website.
3. Click the Upload button

The screenshot shows the 'ADVANCED WEB CONFIGURATION' interface with the 'Station Administration' tab selected. Under the 'Backup and Restore' section, there are two main actions: 'Download Complete Configuration' with a 'DOWNLOAD' button, and 'Upload Configuration File' with a 'Browse...' button. The 'Upload Configuration File' section indicates 'No file selected' and provides a warning: 'File MUST be a valid configuration backup in tar.gz format'. Below this, there are 'UPLOAD' and 'CANCEL' buttons.

When you get the following message click the **Apply** button. The system will reboot

The screenshot shows the 'ADVANCED WEB CONFIGURATION' interface with the 'Station Administration' tab selected. A message is displayed: 'Config file succesfully uploaded! File Size Written = 8696 bytes'. Below this, a warning is shown: 'For all of the restored settings to be applied station reboot is required. Press 'APPLY' Warning: Pressing 'APPLY' will restart the CCoIP-station. Automatic redirect possible if IP Address has been changed. Pressing 'NO' will take you back to the configuration page.' At the bottom of the message, there are two buttons: 'APPLY' and 'NO'.